

INSTALLATION INSTRUCTIONS

MONTAGEANLEITUNG

INSTRUCTION DE MONTAGE

MANUALE DI INSTALLAZIONE

INSTRUCCIONES DE INSTALACION

ΟΔΗΓΕΣ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ

GB

Description:	SUNSHADES	Partnumber:	0078338BC
Application:	JIMNY 3DR	Installation Time:	0.15h

D

Beschreibung:	SONNENSCHUTZ	Teile Nr:	0078338BC
Verwendung:	JIMNY 3DR	Montagezeit:	0.15h

F

Designation:	PARE-SOLEIL	n° de piece:	0078338BC
Utilisation:	JIMNY 3DR	Temps pose:	0.15h

I

Descrizione:	SOLE OMBREGGIA	Numero di codice:	0078338BC
Applicazioni:	JIMNY 3DR	Tempo di installazione:	0.15h

E

Description:	SOMBRILLAS	Numero del parte:	0078338BC
Aplicaciones:	JIMNY 3DR	Tiempo de instalacion:	0.15h

GR

Περιγραφή:	Ηλιοπροστασία	Αρ. ο εξαρτ:	0078338BC
Χρήση:	JIMNY 3DR	Χρονος συναρμολογησης:	0.15h

Contents

Ref.	Description	QTY
1	Sun protection	3
2	Holder A	6
3	Holder B	4
4		
5		

Inhalt

Bez.	Beschreibung	STK.
1	Sonnenschutz	3
2	Holder A	6
3	Holder B	4
4		
5		

Contenu

Réf.	Désignation	QTÉ
1	Protection contre le soleil	3
2	Titulaire A	6
3	Titulaire B	4
4		
5		

Imballo

Rif.	Descrizione	QTA
1	Protezione solare	3
2	Titolare A	6
3	Titolare B	4
4		
5		

Contenido

Ref.	Descripción	UNID
1	Protección solar	3
2	Titular A	6
3	Titular B	4
4		
5		

Περιεχόμενα

Αρ.	Περιγραφή	τεμ.
1	Защита от солнца	3
2	Держатель А	6
3	Держатель В	4
4		





