

MONTAGEANLEITUNG

sun-10495pd-L1-vw · VW T7 Caravelle L1 2025- SunClip Auto Sonnenschutz Panoramadach



DE: Montageanleitung

MT: Istruzzjonijiet għall-assemblaġġ

EN: Installation instructions

NL: Montagehandleiding

DK: Installationsvejledning til

PL: Instrukcje montażu

EE: Paigaldusjuhised

PT: Instruções de montagem

FI: Paigaldusjuhised

RO: Instrucțiuni de asamblare

FR: Instructions de montage

SE: Monteringsanvisningar

GR: Οδηγίες συναρμολόγησης

SK: Návod na montáž

IE: Treoracha tionóil

SI: Navodila za sestavljanje

IT: Istruzioni di montaggio

ES: Instrucciones de montaje

HR: Összeszerelési útmutató


CZ: Návod k montáži

LV: Montāžas instrukcija

HU: Összeszerelési útmutató

LT: Surinkimo instrukcijos

BG: Инструкции за сглобяване



1x PD1



1x PD2



1x PD3



10x SC8-20F



1x

MONTAGEANLEITUNG

sun-10495pd-L1-vw · VW T7 Caravelle L1 2025- SunClip Auto Sonnenschutz Panoramadach

