


Installation Manual

HONDA JAZZ 5DR
HON-JAZZ-5-A



COMPONENTS INCLUDED



CL-P03 x 4



CL-P02 x 4



CL-M03 x 2



CL-W01 x 1



Installation

HONDA JAZZ 5DR

HON-JAZZ-5-A

